

Image not found or type unknown



Ref. No.:

1441-01081630

Overview and Technical Data:

Used MAZAK New Turbo - X510 1.5 KW Laser Cutter

[MAZAK](#)

Year of Build:

May 2001

Description:

Used MAZAK New Turbo - X510 1.5 KW - Cutting machines - Laser

MAZAK New Turbo X510 used - 1.5 kW laser cutting machine for sale

Are you looking for a reliable and powerful laser cutting machine? The used MAZAK New Turbo X510 offers precise CO₂ laser technology with an output of 1.5 kW and is ideal for processing a wide variety of materials.

CNC control: MAZATROL L-32B

On-time 27,833 hrs / total cut 5305 hrs

Technical data of the MAZAK New Turbo - X510:

- Power 1500 KW Panasonic
- Laser type CO?: YB-L 150B 7M
- Metal length 3050 mm
- Metal width 1525 mm
- Maximum thickness 12 mm
- Travel X 3205 mm
- Travel Y 1575 mm
- Travel Z 100 mm
- Maximum workpiece weight 440 kg
- Maximum thickness: structural steel: 12 mm, KO: 6 mm, aluminum: 5 mm

Still Still running and serviced by Primoteq BV

Why buy this MAZAK laser cutting machine?

The used MAZAK laser cutting machine offers an excellent combination of precision, efficiency and reliability. With its high cutting performance, it is ideal for companies looking for a versatile metalworking solution.

Advantages of the MAZAK New Turbo X510:

- Efficient processing of a wide range of metals
- Low operating costs thanks to proven technology
- Maintenance by Primoteq BV – guarantees high reliability
- Still running, ready for inspection

Whether you are buying a laser cutting machine in Germany or are specifically looking for a used MAZAK laser cutting machine – the MAZAK New Turbo X510 is an ideal choice.

Contact us for more information or to arrange a viewing!

Technical Data:

Technical Data:

Control:

[MAZAK](#)

Machine Hours:

27833

Dimensions and Weight:

Weight:

11.900 kg

Buyer Information:

Condition:

[Very good condition](#)

Available:

[Immediately](#)

Sold as:

[EXW \(Ex Works - Incoterm\)](#)

VAT:

[19 %](#)

Buyers Premium:

[18 %](#)

Location:

Netherlands

Images:







touching corners with the machine is running.
2. Know function of each switch before operating.

2. Connaitre la fonction de chaque interrupteur avant utilisation.

2. Machete Sie sich mit jedem Schalter vertraut, bevor Sie die Maschine in Betrieb nehmen.

2. Conoscere ogni tasto prima di utilizzare.

MAZATROL

POWER

HIGH VOLT SHUTTER OPEN LASER POWER

LASER LOCK ENABLE LASER HIGH VOLT

SHUTTER CLOSE OPEN LASER MANUAL DISCHARGE

● READY ● CW ● GAP CONTROL
● BUSY ● H.PULSE ● STYLUS DOWN
● P.HEAD ● S.PULSE
● P.END ● H.PULSE
● NC ALM ● ASSIST GAS ON
● MC ALM ● LASER ALM
● HOLD

OVER RIDE POWER

FREQUENCY DUTY ASSIST GAS

GAP RAPID FEED WINDOW

CYCLE START

*** FDI-0 *** MNo. 7103 TAPET-0 18:23:31

No.	MNo.	SIZE	COMMENT	MODE (AL)	ASPID	40%
1	000	3	ST100		FEED	80%
2	7100	303	NESTING d11	MNo. (71)	POWER	100%
3	7102	325	(STUK 7102		FREQUENCY	100%
4	7103	31	(STUK 7103		DUTY	100%
5	7104	91	(STUK 7104			100%
6	7105	190	(STUK 7105			0.2mm
7	7106	190	(STUK 7106			
8	7107	50	(STUK 7107			
9	7108	100	(STUK 7108			
10	7109	100	(STUK 7109			
11	7110	100	(STUK 7110			
12	7111	151	(STUK 7111			
13	7112	151	(STUK 7112			
14	7113	112	(STUK 7113			
15	7114	112	(STUK 7114			
16	7115	105	(STUK 7115			
	PRG	1	7			

ALL LOAD FUNCTION IS COMPLETED.

200 LUBRICATOR OIL LEVEL DOWN

SET EXTERNAL DEVICE AND EXECUTE

LOAD RELEASE SAVE SAVE ALL DIR WORK No. SELECT START

1 2 3 4 5 6 7 8 9

MPD MF1 MF2

O N G P X Y Z Q I J K R M S T L F D H B

7 8 9 4 5 6 1 2 3 - 0 .

SHIFT ZCR CANCEL CLEAR

COPY MENU OT-RELEASE RESET

PAGE

INPUT

POSITION PROGRAM OFFSET PARA-SETTER PRESS. DATA

GRAPH DATA ALARM SWITTM

HANDLE RAPID JOG HOME

AUTO MEL

PROGRAM EDIT

LOCK UNLOCK

COVER OPEN WORK LIGHT EXHAUST UNIT AUTO POWER OFF ALARM POWER OFF ON LINE NON CONTACT SENSOR MACHINE SET UP PERMISSION

(SUB

POSITION

DISTANCE

X 37.193
Y 649.693
Z -143.899

X -2
Y 2
Z 0

MACHINE

REMAIN

X -3153.058
Y -873.477
Z -143.899

X 0
Y 41
Z 0

FEED 870 mm/min

CO

NNo. 2
BNo. 34

PO
AL
AL
TO

289 LUBRICATOR OIL LEVEL

SEQ. No. SET	MODAL INFORM	PROGRAM MONITOR
-----------------	-----------------	--------------------



Asset-Trade

Assessment and Sale of Used Assets world wide

Am Sonnenhof 16

47800 Krefeld

Germany

Tel.: +49 2151 32500 33

Fax.: +49 2151 65 29 22

Email: info@asset-trade.de

Web.: <https://www.asset-trade.de/en>

Ref. No.:
1441-01081630

Overview and Technical Data:

Used MAZAK New Turbo - X510 1.5 KW Laser Cutter

[MAZAK](#)

Year of Build:
May 2001

Description:

Used MAZAK New Turbo - X510 1.5 KW - Cutting machines - Laser

MAZAK New Turbo X510 used - 1.5 kW laser cutting machine for sale

Are you looking for a reliable and powerful laser cutting machine? The used MAZAK New Turbo X510 offers precise CO₂ laser technology with an output of 1.5 kW and is ideal for processing a wide variety of materials.

CNC control: MAZATROL L-32B

On-time 27,833 hrs / total cut 5305 hrs

Technical data of the MAZAK New Turbo - X510:

- Power 1500 KW Panasonic
- Laser type CO₂: YB-L 150B 7M
- Metal length 3050 mm
- Metal width 1525 mm
- Maximum thickness 12 mm
- Travel X 3205 mm
- Travel Y 1575 mm
- Travel Z 100 mm

- Maximum workpiece weight 440 kg
- Maximum thickness: structural steel: 12 mm, KO: 6 mm, aluminum: 5 mm

Still running and serviced by Primoteq BV

Why buy this MAZAK laser cutting machine?

The used MAZAK laser cutting machine offers an excellent combination of precision, efficiency and reliability. With its high cutting performance, it is ideal for companies looking for a versatile metalworking solution.

Advantages of the MAZAK New Turbo X510:

- Efficient processing of a wide range of metals
- Low operating costs thanks to proven technology
- Maintenance by Primoteq BV – guarantees high reliability
- Still running, ready for inspection

Whether you are buying a laser cutting machine in Germany or are specifically looking for a used MAZAK laser cutting machine – the MAZAK New Turbo X510 is an ideal choice.

Contact us for more information or to arrange a viewing!

Technical Data:

Technical Data:

Control:

[MAZAK](#)

Machine Hours:

27833

Dimensions and Weight:

Weight:

11.900 kg

Buyer Information:

Condition:

[Very good condition](#)

Available:

[Immediately](#)

Sold as:

[EXW \(Ex Works - Incoterm\)](#)

VAT:

[19 %](#)

Buyers Premium:

[18 %](#)

Location:
Netherlands

Images:





MAZAK

WARNING	AVERTISSEMENT	ACHTUNG	AVVERTENZA
1. Read the safety instructions carefully and be sure to understand the meaning of each symbol before operating the machine.	1. Lire attentivement les instructions de sécurité et s'assurer de comprendre le sens de chaque symbole avant d'utiliser la machine.	1. Lesen Sie die Sicherheitsanweisungen sorgfältig und stellen Sie sicher, dass Sie die Bedeutung jedes Symbols verstehen, bevor Sie die Maschine in Betrieb nehmen.	1. Leggere attentamente le istruzioni di sicurezza e assicurarsi di comprendere il significato di ogni simbolo prima di utilizzare la macchina.

MAZATROL

POWER

HIGH VOLT SHUTTER OPEN LASER POWER
 LASER LOCK ENABLE LASER HIGH VOLT

1. 1000.000
 2. 1000.000
 3. 1000.000
 4. 1000.000
 5. 1000.000
 6. 1000.000
 7. 1000.000
 8. 1000.000
 9. 1000.000
 10. 1000.000
 11. 1000.000
 12. 1000.000
 13. 1000.000
 14. 1000.000
 15. 1000.000
 16. 1000.000
 17. 1000.000
 18. 1000.000
 19. 1000.000
 20. 1000.000
 21. 1000.000
 22. 1000.000
 23. 1000.000
 24. 1000.000
 25. 1000.000
 26. 1000.000
 27. 1000.000
 28. 1000.000
 29. 1000.000
 30. 1000.000
 31. 1000.000
 32. 1000.000
 33. 1000.000
 34. 1000.000
 35. 1000.000
 36. 1000.000
 37. 1000.000
 38. 1000.000
 39. 1000.000
 40. 1000.000
 41. 1000.000
 42. 1000.000
 43. 1000.000
 44. 1000.000
 45. 1000.000
 46. 1000.000
 47. 1000.000
 48. 1000.000
 49. 1000.000
 50. 1000.000
 51. 1000.000
 52. 1000.000
 53. 1000.000
 54. 1000.000
 55. 1000.000
 56. 1000.000
 57. 1000.000
 58. 1000.000
 59. 1000.000
 60. 1000.000
 61. 1000.000
 62. 1000.000
 63. 1000.000
 64. 1000.000
 65. 1000.000
 66. 1000.000
 67. 1000.000
 68. 1000.000
 69. 1000.000
 70. 1000.000
 71. 1000.000
 72. 1000.000
 73. 1000.000
 74. 1000.000
 75. 1000.000
 76. 1000.000
 77. 1000.000
 78. 1000.000
 79. 1000.000
 80. 1000.000
 81. 1000.000
 82. 1000.000
 83. 1000.000
 84. 1000.000
 85. 1000.000
 86. 1000.000
 87. 1000.000
 88. 1000.000
 89. 1000.000
 90. 1000.000
 91. 1000.000
 92. 1000.000
 93. 1000.000
 94. 1000.000
 95. 1000.000
 96. 1000.000
 97. 1000.000
 98. 1000.000
 99. 1000.000
 100. 1000.000

SHUTTER CLOSE OPEN DISCHARGE
 LASER MANUAL

1. REAR 2. ON 3. SP. SP. 200-100
 4. REAR 5. SP. SP. 200-100
 6. REAR 7. SP. SP. 200-100
 8. REAR 9. SP. SP. 200-100
 10. REAR 11. SP. SP. 200-100
 12. REAR 13. SP. SP. 200-100
 14. REAR 15. SP. SP. 200-100
 16. REAR 17. SP. SP. 200-100
 18. REAR 19. SP. SP. 200-100
 20. REAR 21. SP. SP. 200-100
 22. REAR 23. SP. SP. 200-100
 24. REAR 25. SP. SP. 200-100
 26. REAR 27. SP. SP. 200-100
 28. REAR 29. SP. SP. 200-100
 30. REAR 31. SP. SP. 200-100
 32. REAR 33. SP. SP. 200-100
 34. REAR 35. SP. SP. 200-100
 36. REAR 37. SP. SP. 200-100
 38. REAR 39. SP. SP. 200-100
 40. REAR 41. SP. SP. 200-100
 42. REAR 43. SP. SP. 200-100
 44. REAR 45. SP. SP. 200-100
 46. REAR 47. SP. SP. 200-100
 48. REAR 49. SP. SP. 200-100
 50. REAR 51. SP. SP. 200-100
 52. REAR 53. SP. SP. 200-100
 54. REAR 55. SP. SP. 200-100
 56. REAR 57. SP. SP. 200-100
 58. REAR 59. SP. SP. 200-100
 60. REAR 61. SP. SP. 200-100
 62. REAR 63. SP. SP. 200-100
 64. REAR 65. SP. SP. 200-100
 66. REAR 67. SP. SP. 200-100
 68. REAR 69. SP. SP. 200-100
 70. REAR 71. SP. SP. 200-100
 72. REAR 73. SP. SP. 200-100
 74. REAR 75. SP. SP. 200-100
 76. REAR 77. SP. SP. 200-100
 78. REAR 79. SP. SP. 200-100
 80. REAR 81. SP. SP. 200-100
 82. REAR 83. SP. SP. 200-100
 84. REAR 85. SP. SP. 200-100
 86. REAR 87. SP. SP. 200-100
 88. REAR 89. SP. SP. 200-100
 90. REAR 91. SP. SP. 200-100
 92. REAR 93. SP. SP. 200-100
 94. REAR 95. SP. SP. 200-100
 96. REAR 97. SP. SP. 200-100
 98. REAR 99. SP. SP. 200-100
 100. REAR 101. SP. SP. 200-100

OVER RIDE POWER
 FREQUENCY
 RAMP
 AUTO
 ASSIST LINE
 INCH
 FEED
 INCH
 FEED

O N G P
 X Y Z Q
 I J K R
 M S T L
 F D H B
 7 8 9
 4 5 6
 1 2 3
 0
 + - * /
 =

+ - * /
 =

+ - * /
 =

1. REAR 2. ON 3. SP. SP. 200-100
 4. REAR 5. SP. SP. 200-100
 6. REAR 7. SP. SP. 200-100
 8. REAR 9. SP. SP. 200-100
 10. REAR 11. SP. SP. 200-100
 12. REAR 13. SP. SP. 200-100
 14. REAR 15. SP. SP. 200-100
 16. REAR 17. SP. SP. 200-100
 18. REAR 19. SP. SP. 200-100
 20. REAR 21. SP. SP. 200-100
 22. REAR 23. SP. SP. 200-100
 24. REAR 25. SP. SP. 200-100
 26. REAR 27. SP. SP. 200-100
 28. REAR 29. SP. SP. 200-100
 30. REAR 31. SP. SP. 200-100
 32. REAR 33. SP. SP. 200-100
 34. REAR 35. SP. SP. 200-100
 36. REAR 37. SP. SP. 200-100
 38. REAR 39. SP. SP. 200-100
 40. REAR 41. SP. SP. 200-100
 42. REAR 43. SP. SP. 200-100
 44. REAR 45. SP. SP. 200-100
 46. REAR 47. SP. SP. 200-100
 48. REAR 49. SP. SP. 200-100
 50. REAR 51. SP. SP. 200-100
 52. REAR 53. SP. SP. 200-100
 54. REAR 55. SP. SP. 200-100
 56. REAR 57. SP. SP. 200-100
 58. REAR 59. SP. SP. 200-100
 60. REAR 61. SP. SP. 200-100
 62. REAR 63. SP. SP. 200-100
 64. REAR 65. SP. SP. 200-100
 66. REAR 67. SP. SP. 200-100
 68. REAR 69. SP. SP. 200-100
 70. REAR 71. SP. SP. 200-100
 72. REAR 73. SP. SP. 200-100
 74. REAR 75. SP. SP. 200-100
 76. REAR 77. SP. SP. 200-100
 78. REAR 79. SP. SP. 200-100
 80. REAR 81. SP. SP. 200-100
 82. REAR 83. SP. SP. 200-100
 84. REAR 85. SP. SP. 200-100
 86. REAR 87. SP. SP. 200-100
 88. REAR 89. SP. SP. 200-100
 90. REAR 91. SP. SP. 200-100
 92. REAR 93. SP. SP. 200-100
 94. REAR 95. SP. SP. 200-100
 96. REAR 97. SP. SP. 200-100
 98. REAR 99. SP. SP. 200-100
 100. REAR 101. SP. SP. 200-100

1. REAR 2. ON 3. SP. SP. 200-100
 4. REAR 5. SP. SP. 200-100
 6. REAR 7. SP. SP. 200-100
 8. REAR 9. SP. SP. 200-100
 10. REAR 11. SP. SP. 200-100
 12. REAR 13. SP. SP. 200-100
 14. REAR 15. SP. SP. 200-100
 16. REAR 17. SP. SP. 200-100
 18. REAR 19. SP. SP. 200-100
 20. REAR 21. SP. SP. 200-100
 22. REAR 23. SP. SP. 200-100
 24. REAR 25. SP. SP. 200-100
 26. REAR 27. SP. SP. 200-100
 28. REAR 29. SP. SP. 200-100
 30. REAR 31. SP. SP. 200-100
 32. REAR 33. SP. SP. 200-100
 34. REAR 35. SP. SP. 200-100
 36. REAR 37. SP. SP. 200-100
 38. REAR 39. SP. SP. 200-100
 40. REAR 41. SP. SP. 200-100
 42. REAR 43. SP. SP. 200-100
 44. REAR 45. SP. SP. 200-100
 46. REAR 47. SP. SP. 200-100
 48. REAR 49. SP. SP. 200-100
 50. REAR 51. SP. SP. 200-100
 52. REAR 53. SP. SP. 200-100
 54. REAR 55. SP. SP. 200-100
 56. REAR 57. SP. SP. 200-100
 58. REAR 59. SP. SP. 200-100
 60. REAR 61. SP. SP. 200-100
 62. REAR 63. SP. SP. 200-100
 64. REAR 65. SP. SP. 200-100
 66. REAR 67. SP. SP. 200-100
 68. REAR 69. SP. SP. 200-100
 70. REAR 71. SP. SP. 200-100
 72. REAR 73. SP. SP. 200-100
 74. REAR 75. SP. SP. 200-100
 76. REAR 77. SP. SP. 200-100
 78. REAR 79. SP. SP. 200-100
 80. REAR 81. SP. SP. 200-100
 82. REAR 83. SP. SP. 200-100
 84. REAR 85. SP. SP. 200-100
 86. REAR 87. SP. SP. 200-100
 88. REAR 89. SP. SP. 200-100
 90. REAR 91. SP. SP. 200-100
 92. REAR 93. SP. SP. 200-100
 94. REAR 95. SP. SP. 200-100
 96. REAR 97. SP. SP. 200-100
 98. REAR 99. SP. SP. 200-100
 100. REAR 101. SP. SP. 200-100

LASER OPEN LASER LIGHT EXHAUST UNIT AUTO POWER OFF ALARM POWER OFF ON LINE NON CONTACT SENSOR
 PROGRAM EDIT
 MACHINE SET UP PERMITS

WARNING	AVVERTENZA
1. Read the safety instructions carefully and be sure to understand the meaning of each symbol before operating the machine.	1. Leggere attentamente le istruzioni di sicurezza e assicurarsi di comprendere il significato di ogni simbolo prima di utilizzare la macchina.

WARNING	AVVERTENZA
1. Read the safety instructions carefully and be sure to understand the meaning of each symbol before operating the machine.	1. Leggere attentamente le istruzioni di sicurezza e assicurarsi di comprendere il significato di ogni simbolo prima di utilizzare la macchina.

touching corners with the machine is running.
2. Know function of each switch before operating.

2. Connaitre la fonction de chaque interrupteur avant utilisation.

2. Machete Sie sich mit jedem Schalter vertraut, bevor Sie die Maschine in Betrieb nehmen.

2. Conoscere ogni testato utilizzarlo.

MAZATROL

POWER

HIGH VOLT SHUTTER OPEN LASER POWER

LASER LOCK ENABLE LASER HIGH VOLT

SHUTTER CLOSE OPEN LASER MANUAL DISCHARGE

READY BUSY P.HEAD P.END ? NC ALM ? MC ALM HOLD

CW H.PULSE S.PULSE H.PULSE ? ASSIST GAS ON ? LASER ALM

GAP CONTROL STYLUS DOWN X Y Z 4

OVER RIDE POWER GAP

FREQUENCY DUTY ASSIST GAS

RAPID FEED WINDOW

CYCLE START

*** FDI-0 *** MNo. 7103 TAPET-0 18:23:31

No.	MNo.	SIZE	COMMENT	MODE (AL)	ASPID	FEED	POWER	FREQUENCY	DUTY	OFFSET
1	000	3	ST100			40%				
2	7100	303	NESTING d11			80%				
3	7102	325	(STUK 7102			100%				
4	7103	31	(STUK 7103			100%				
5	7104	91	(STUK 7104			100%				
6	7105	190	(STUK 7105			100%				0.2mm
7	7106	190	(STUK 7106							
8	7107	50	(STUK 7107							
9	7108	100	(STUK 7108							
10	7109	100	(STUK 7109							
11	7110	100	(STUK 7110							
12	7111	151	(STUK 7111							
13	7112	151	(STUK 7112							
14	7113	112	(STUK 7113							
15	7114	112	(STUK 7114							
16	7115	105	(STUK 7115							
17	7116	105	(STUK 7116							
18	7117	105	(STUK 7117							
19	7118	105	(STUK 7118							
20	7119	105	(STUK 7119							
21	7120	105	(STUK 7120							
22	7121	105	(STUK 7121							
23	7122	105	(STUK 7122							
24	7123	105	(STUK 7123							
25	7124	105	(STUK 7124							
26	7125	105	(STUK 7125							
27	7126	105	(STUK 7126							
28	7127	105	(STUK 7127							
29	7128	105	(STUK 7128							
30	7129	105	(STUK 7129							
31	7130	105	(STUK 7130							
32	7131	105	(STUK 7131							
33	7132	105	(STUK 7132							
34	7133	105	(STUK 7133							
35	7134	105	(STUK 7134							
36	7135	105	(STUK 7135							
37	7136	105	(STUK 7136							
38	7137	105	(STUK 7137							
39	7138	105	(STUK 7138							
40	7139	105	(STUK 7139							
41	7140	105	(STUK 7140							
42	7141	105	(STUK 7141							
43	7142	105	(STUK 7142							
44	7143	105	(STUK 7143							
45	7144	105	(STUK 7144							
46	7145	105	(STUK 7145							
47	7146	105	(STUK 7146							
48	7147	105	(STUK 7147							
49	7148	105	(STUK 7148							
50	7149	105	(STUK 7149							
51	7150	105	(STUK 7150							
52	7151	105	(STUK 7151							
53	7152	105	(STUK 7152							
54	7153	105	(STUK 7153							
55	7154	105	(STUK 7154							
56	7155	105	(STUK 7155							
57	7156	105	(STUK 7156							
58	7157	105	(STUK 7157							
59	7158	105	(STUK 7158							
60	7159	105	(STUK 7159							
61	7160	105	(STUK 7160							
62	7161	105	(STUK 7161							
63	7162	105	(STUK 7162							
64	7163	105	(STUK 7163							
65	7164	105	(STUK 7164							
66	7165	105	(STUK 7165							
67	7166	105	(STUK 7166							
68	7167	105	(STUK 7167							
69	7168	105	(STUK 7168							
70	7169	105	(STUK 7169							
71	7170	105	(STUK 7170							
72	7171	105	(STUK 7171							
73	7172	105	(STUK 7172							
74	7173	105	(STUK 7173							
75	7174	105	(STUK 7174							
76	7175	105	(STUK 7175							
77	7176	105	(STUK 7176							
78	7177	105	(STUK 7177							
79	7178	105	(STUK 7178							
80	7179	105	(STUK 7179							
81	7180	105	(STUK 7180							
82	7181	105	(STUK 7181							
83	7182	105	(STUK 7182							
84	7183	105	(STUK 7183							
85	7184	105	(STUK 7184							
86	7185	105	(STUK 7185							
87	7186	105	(STUK 7186							
88	7187	105	(STUK 7187							
89	7188	105	(STUK 7188							
90	7189	105	(STUK 7189							
91	7190	105	(STUK 7190							
92	7191	105	(STUK 7191							
93	7192	105	(STUK 7192							
94	7193	105	(STUK 7193							
95	7194	105	(STUK 7194							
96	7195	105	(STUK 7195							
97	7196	105	(STUK 7196							
98	7197	105	(STUK 7197							
99	7198	105	(STUK 7198							
100	7199	105	(STUK 7199							

ALL LOAD FUNCTION IS COMPLETED.

200 LUBRICATOR OIL LEVEL DOWN

SET EXTERNAL DEVICE AND EXECUTE

LOAD RELEASE SAVE SAVE ALL DIR WORK No. SELECT START

1 2 3 4 5 6 7 8 9

MPD MF1 MF2

O N G P X Y Z Q I J K R M S T L F D H B

7 8 9 4 5 6 1 2 3 - 0 .

SHIFT ZON CANCEL CLEAR

COPY MENU OT-RELEASE RESET

PAGE

INPUT

POSITION PROGRAM OFFSET PARA-SETTER PRESET DATA

GRAPH DATA ALARM SWITCH

HANDLE RAPID JOG HOME

AUTO MEL

+X -X

CYCLE START

PROGRAM EDIT

COVER OPEN WORK LIGHT EXHAUST UNIT AUTO POWER OFF ALARM POWER OFF ON LINE NON CONTACT SENSOR MACHINE SET UP PERMISSION

(SUB

POSITION

DISTANCE

X 37.193
Y 649.693
Z -143.899

X -2
Y 2
Z 0

MACHINE

REMAIN

X -3153.058
Y -873.477
Z -143.899

X 0
Y 41
Z 0

FEED 870 mm/min

CO

NNo. 2
BNo. 34

PO

AL

AL

TO

289 LUBRICATOR OIL LEVEL

SEQ. No. SET	MODAL INFORM	PROGRAM MONITOR
-----------------	-----------------	--------------------



Asset-Trade

Assessment and Sale of Used Assets world wide

Am Sonnenhof 16

47800 Krefeld

Germany

Tel.: +49 2151 32500 33

Fax.: +49 2151 65 29 22

Email: info@asset-trade.de

Web.: <https://www.asset-trade.de/en>

Generated on 02.02.2026

© Copyright 2026 - [Asset-Trade](#)

Page